



tellus m eco

tunableWhite

Operation Manual

Dear customer,

Thank you for choosing our product.

Please read this user manual carefully before using the product. This manual is part of the product and should be kept in a safe place for future reference. If you pass the product on to third parties, please also pass on this operation manual.

Safety Instructions

- ⚠ Connection and operation of this device should only be performed by qualified personnel in accordance with all applicable regulations.
- ⚠ Always observe the technical specifications provided in the datasheet.
- ⚠ Subject to technical modifications.
- ⚠ The included operating instructions are essential for proper use.
- ⚠ The wire assignment must comply with the wiring diagram!
- ⚠ Before starting work, ensure the power supply is disconnected and voltage-free!
- ⚠ Protection against electric shock must be ensured during installation.
- ⚠ We recommend additional on-site protection via a residual current device (RCD).
- ⚠ During installation, ensure that adjacent components can withstand a temperature of 90°C.
- ⚠ Do not operate the luminaire on the same circuit as inductive loads (fluorescent lamps, discharge lamps, fans, etc.). Switching inductive loads may cause damage to the luminaire.
- ⚠ Insulation must not rest on the luminaire.
- ⚠ Observe the operating temperature specified in the technical data during installation!
- ⚠ When drilling mounting holes, ensure that the mains cables are not damaged.
- ⚠ Stranded wires must not be tinned. Ferrules must be used.
- ⚠ Observe the voltage marking on the control gear.
- ⚠ Ensure a proper electrical connection when connecting the luminaire.
- ⚠ If the luminaire is connected to the power supply while under load, it may be damaged! (Not covered under warranty.)
- ⚠ Any modification is prohibited. The manufacturer assumes no liability for damages resulting from alterations, improper use, or incorrect installation.
- ⚠ Store the device in a dry location and protect it from damage!

SCOPE OF DELIVERY

If you notice any transport damage or discrepancies between the specified delivery contents and the packaging contents, please notify your point of sale immediately.

OPERATION

DMX / RDM DMX - Modes of operation and DMX-Footprints

Product name	Modes + DMX Footprints Modes	Resolution	DMX
--------------	---------------------------------	------------	-----

DMX / RDM RDM - Remote Device Management Protocol

BION Technologies luminaires integrate seamlessly with DMX512 networks, utilizing the RDM protocol defined by ANSI E1.20.

The RDM protocol enables effortless discovery, configuration, monitoring, and management of your luminaires. RDM elevates lighting control by providing real-time fixture monitoring, customizable settings adjustments, and fast fault diagnosis. BION luminaires support a comprehensive range of RDM Parameter IDs.

The following parameters can be read and set via RDM.

Parameter IDs	GET	SET
DISC_UNIQUE_BRANCH		
DISC_MUTE		
DISC_UN_MUTE		
SUPPORTED_PARAMETERS		
DEVICE_INFO		
DEVICE_MODEL_DESCRIPTION		
MANUFACTURER_LABEL		
DEVICE_LABEL		
SOFTWARE_VERSION_LABEL		
DMX_PERSONALITY		
DMX_PERSONALITY_DESCRIPTION		
DMX_START_ADDRESS		
SENSOR_DEFINITION		
SENSOR_VALUE		
DEVICE_HOURS		
DEVICE_POWER_CYCLES		

GENERAL
MAINTENANCE

APPROBATION(S):

MANUFACTURER

Bion Technologies GmbH

Lindberghstrasse 15
86343 Koenigsbrunn

Tel: +49 (0)8231/95787-0
Fax: +49 (0)8231/95787-29

www.biontechnologies.com
info@biontechnologies.com

*All rights reserved / Subject to change /
Specifications may change without notice*

